# Singer 81-24

Form 18651, Revised (939) Printed in U.S.A.

# LIST of PARTS



MACHINE No. 81-24

THE SINGER MANUFACTURING COMPANY

# INSTRUCTIONS FOR OILING

To ensure easy running and prevent unnecessary wear of the parts which are in movable contact, the machine requires oiling and when in continuous use, it should be oiled at least twice each day by applying Singer Cloth and Leather Oil to all oil holes marked "Oil" and to all other oiling places.

Copyright, U. S. A., 1931 and 1939
by The Singer Manufacturing Co.
All Rights Reserved for all Countries.

#### **INDEX**

	Page
Accessories,	
Foot Lifter Parts	. 1
Knife Grinder	. 13
Knee Lifter Parts	. 1
Machine Base	. 1
Machine No. 81-24	. !
Numerical List of Parts	. 1
Thread Unwinder	. 1
Parts Required to Change from Single Thread Chain Stitch to a Two-Thread Chain Stitch	. 1

#### INSTRUCTIONS FOR ORDERING

In ordering from this list, use ONLY the part NUMBER in the FIRST column.

The number stamped on a Sewing Machine Part is in every case the number of the single part only.

Every combination of parts sent out as such has its specific number, which, although not stamped on the parts, must be used when ordering the combination.

Each number always indicates the SAME PART in whatever list it appears, or for whatever machine.

The letters after some of the numbers indicate the style of finish only, as follows:

A-Hardened, Polished, Nickel Plated and Buffed

A.A-Buffed and Chromium Plated

A.B-Hardened, Polished, Buffed and Chromium Plated

B-Polished, Nickel Plated and Buffed

C-Hardened Only

C.R-Hardened and Merlized

D-Polished Only

E-Soft, Not Polished

F-Hardened and Polished

F.J-Hardened, Polished and Nickel Plated

G-Bright Rumbled and Nickel Plated

H-Blued

J-Nickel Plated Only

K-Hardened and Nickel Plated

L-Brass Plated

M-0xidized

N-Japanned, Dull

P-Japanned, Bright

P.P-Wrinkle Finish

R-Merlized

S-Cadmium Plated

T-Copper Plated

T.A-Hardened, Polished, Copper and Nickel Plated and Buffed

T.B-Copper and Nickel Plated and Polished

T.J-Copper and Nickel Plated Only

T.K-Hardened, Copper and Nickel Plated

T.L-Copper and Brass Plated

T.M-Copper Plated and Oxidized

U-Zinc Plated

V-Silver Plated

W-Polished and Nickel Plated

X-Black Oxide, for Iron and Steel

X.C-Hardened and Black Oxide, for Iron or Steel

Y-Black Nickel Plated Only

Z-Chromium Plated

Z.A-Hardened, Polished, Nickel Plated, Buffed and Chromium Plated

Z.B-Polished, Nickel Plated, Buffed and Chromium Plated

Z.C-Hardened and Chromium Plated

Z.D-Polished and Chromium Flated

2.G-Bright Rumbled, Nickel Plated, Bright Rumbled and Chromium Plated

ď

Z.J-Nickel and Chromium Plated

Z.T-Copper and Chromium Plated

These letters MUST BE USED when they appear in the list; and AFTER the number as in the list.

In this series:

1 to 1500, 50001 to 51500 and 140001 to 142000 are Screw Numbers

1501 to 1800 and 51501 to 51800 are Nut Numbers


1801 to 2000 and 51801 to 52000 are Roller Numbers 2001 to 50000 and 52001 to 140000 and 142001 to

190000 are Sewing Machine Parts, 190001 and upward are numbers of Electrical Parts.

The figures in the second column refer only to the plates, illustrating the parts, and are NOT TO BE USED in ordering.

Parts marked with an asterisk (\*) are furnished only when repairs are made at factory.

LIST.OF PARTS COMPLETE FOR



MACHINE No. 81-24

For trimming and joining the abutted edges, of piece goods. The bight is adjustable from  $\frac{5}{16}$  inch to  $\frac{3}{8}$  inch. The machine is regularly furnished for single thread chain stitch. If so ordered it can be fitted for two-thread chain stitch. Foot Lifter. Speed up to 3000.

NOTE: THE MACHINE CAN ALSO BE FURNISHED FOR 1/4
INCH BIGHT FOR FOLDED OR ABUTTED EDGE.

No. *42485	Plate	Name Arm with 15404 and two each 462C, 624C, 15405, 42253 and 42487
4389	23042	Arm Dowel Pin
949E	23042	" Screw
42001	23038	Balance Wheel, 2 3/16 in. pulley, with 424C and 1354C
1354C	23038	Balance Wheel Position Screw
424C	23038	" " Set Screw
132501	23039	Cloth Plate

No.	Plate	Name
42231	23039	Cloth Plate Extension (bottom)
229E	23039	" " " Screw
132502	23039	" " (top)
229E	23039	" " " Screw
132503	23039	Cloth Plate complete, Nos. 42005, 42231,
		132501,132502, two 236J and five 229E
1437D	23039	Cloth Plate Hinge Screw
1655E	23039	" " Nut.
42005	23039	" Lock Spring
236J	23039	" " Screw
42205	23040	Feed Bar with 1253C
42007	23040	" Hinge Pin
1253C	23040	" " " Set Screw
42008	23038	" Connecting Rod with two 1057C
1057C	23038	" Cap Screw
1373C	23038	# " Hinge Screw
1520C	23038	# # " Nut
132504	23040	Dog, 14 teeth (10 teeth to the
200001	20010	inch) for 132521
190D	23040	Feed Dog Screw
42011	23038	* Eccentric with two 4530
132505	23042	" Cover
42102	23042	" " Holder
132604		" " 42102 with
		42101, 132505, 132931 and two each
		190J and 207J
283D	23042	Feed Eccentric Cover Holder Thumb Screw.
19044	23042	и и и и и и
		Washer
207J	23042	Feed Eccentric Cover Screw
453C	23038	" " Set Screw
132506	23038	" Lifting Eccentric with two 4620
42013	23038	" " Connection
462C	23038	" " Set Screw
_ 1374C	23040	* Regulating Screw Stud
1680C	23040	" " Nut
42290	23040	" " " " Washer
42014	23040	" Regulator with 233J and two 1259C
42015	23040	" Connection with 1012E
1012E	23040	" " Adjusting
		Screw
1373C	23040	Feed Regulator Connection Hinge Screw
1520J	23040	" " " " Nut
42016	23040	" " Hinge Stud
1259C	23040	" Set Screw
233J	23040	" Stop Screw
42019	23040	* Rock Shaft
42021	23040	" " Crank with 157E
157E	23040	" " Clamping Screw
42020		Feed Rock Shaft complete, Nos. 42019 and
		42021
		,

••-	D1 - 4 -	Nome
No.	Plate	Name
42098	23040	Feed Rock Shaft Hinge Pin  Bushing
42079 10360	23040 23040	" " * * * Set Screw
*132507	23040	Frame
*132507 42210	23038	" Rotary Shaft
42024	23038	" " Bushing (front)
1036C	23038	" " " Set Screw
42211	23038	" " Crank with 1036C and
46611	2000	13750
1375C	23038	Frame Rotary Shaft Crank Position Screw.
1036C	23038	" " " Set Screw
42026	23038	" " Flanged Bushing (back)
		with 54967
54967	23038	Frame Rotary Shaft Flanged Bushing
		(back) 011 Pad (braided cotton)
1036C	23038	Frame Rotary Shaft Flanged Bushing
		(back) Set Screw
42367	23038	Frame Rotary Shaft Front Bearing Oil Pad
		(braided cotton)
132638	23039	Frame Side Cover (left) with 132701
132701	23039	" " " Handle
330W	23039	" " " Screw
42028	23039	" " (right) hinged
42101	23042	" " " Lock Spring
190J	23042	" " " " " Screw
330W	23039	" " " Screw
132508	23039	" Top Cover
132300	23042	* * " Extension
132931.		" " " 132300 with 132511
		and two 337W
132511	23042	Frame Top Cover Extension Chaining-off
		Finger
337W	23042	Frame Top Cover Extension Chaining-off
		Finger Screw
190J	23042	Frame Top Cover Extension Screw
742F	23039 23042	" " Screw
42305		No. 42305 are sent with this machine.
42306	e: Two 23042	Knife (movable) Gib
132926	23042	" Holder
132927	20042	" " 132926 with 133F.
102927		42040, 42306, 132928 and two 220E
132928	23042	Knife (movable) Holder Cap
220E	23042	" " Screw
42038	23042	" " Guide with 336F
42039	23042	" " " Plate
42003 621E	23042	" " " " Screw
336F	23042	" " " Set Screw
133F	23042	" " Screw
42040	23042	" " Extension Pin
TOTO	200.20	

No.	Plate			Name			
42041	23042	Knife (m	ovable)	Holder	Spring.		
42042	23042	я	ŧī	Lever.			
132512	23042	91	H.	Ħ	Bracket	with 1036C	
949E	23042	₩.	#	#	tt .	Screw	
42217	23038	m	"	" C	onnectio	n with two	
		175E					
175E	23038				Connecti		
1373C	23038					on Hinge	
20.00		Scre	W				
1520C	23038					on Hinge	
10.000	20000						
42045	23042					ud	
1036C	23042	"	e			Set Screw	
42309	23041	" (	tationa	rv) wit			
Not		No. 42309					
42310	23041					ad	
1534D	23041	u tritte /r	#	137 010		Thumb Nut	
132513	23041	£		¥o1			
	23041	Ħ	n	1101		ting Thumb	
1376C	20041	Cam			_		
33030	23041	Matta /	:* :+a+1.opo	Toll (um	der Sere	w	
1101C		unite /:	8 02 01 0110	11.97 IIOI	dor bore		
42049	23041	Loopon					
132514	23041						
132870	23041						
42052	23041		# CC	mnec 611.		linge Screw	
50562C	23041				11	in a	
1520C	23041			-			
						•••••	
42053	23041	Looper .	reaer. Hi	inge su		rew	
1036C	23041				200 00		
50117C	23041						
38534	23041	иесте	-	-		********	
42253	23041	11	" Busi	_			
462C	23041		* Com				
42291	23041		COIII			with 223F	
1057C	23041			_		Clamping	
						• • • • • • • • • • • • •	
42055	23041	Needle	Bar Cont	necting			•
40247	23041	,, H	n	,,	" HI	nge Pin	
223 <b>F</b>	23041				"		
904C	23041			_		nge Pin Set	
42057	23038			necting	Rod Wit	four 896C	
896C	23038	п	#		" Cap	(lower)	
			ew		• • • • • • •	• • • • • • • • • • • •	
896C	23038			_	Rod Cap		
		Scr	ew		• • • • • • •		

No.	Plate	Name
NO. 42077	23038	Needle Bar Connecting Rod Guide
	23038	. " " " " Screw
171F		" " Crank (back) with 1258C and
42103	23041	
	00000	two 1259C  Needle Bar Crank (back) Ball Stud
42074	23038	needle Bar Crank (back) Ball Stud
1259C	23041	DC0 DOICH
1259C	23041	LOST FLOR DOLEM.
1258C	23041	Bec perew
42104	23041	" (If OHE) WICH 9040,12000
		and 1259C
1259C	23041	Needle Bar Crank (front) Position Screw.
1258C	23041	" " Set Screw
42105	23041	" " Shaft
42487	23041	" " " Bushing
624C	23041	" " " " Set Screw.
42115	23041	" Thread Retainer Bracket
228J	23041	m m m m m Screw
42483	23041	" " " Disc
93C	23041	" " " Screw
10107	23041	" " " Spring
1737C	23041	* Clamping Nut
132515	23041	" Guard
171F	23041	" Screw
132516	23040	Presser Foot with 233J and 132517
132517	23040	" " Chaining-off Finger
	23040	" " Screw
233J	23040	" Screw
1324C		" " Washer
39541	23040	#CD1Q1
132518	23040	" Lever 132518 with 42045
132605		
42045	23040	" " Hinge Stud" " " Set Screw
1120C	23040	" Det Dolew
132519	23040	TTT PGT **************
50378F	23040	" " BCIEW (Dack)
1547J	23040	" " " Nuc
190D	23040	(110110)
42071	23040	" * Spring
1378J	23040	Pressure Regulating Thumb Screw
42250	23041	Spreader
42073	23041	" Lever with 1259C
42221	23038	" " Ball Stud
1259C	23041	" " " Set Screw
42075	23038	" " Connection with four 8960
896C	23038	<pre>" " Cap (lower)</pre>
0040		Screw
896C	23038	Spreader Lever Connection Cap (upper)
3300	2200	Screw
42077	23038	Spreader Lever Connection Guide
42077 171F	23038	" " " Screw
42106	23038	" " " Oil Tube and
46100 ·	2000	Bracket with 29599
		Didover Atom propossion

n e

L.

No.	Plate			Name
42088	23044	Machine	Cushion	(felt)
935E	23044		Ħ	Screw
66707	23044	Ħ	Ħ	# Washer

### FOOT LIFTER PARTS

No.	Plate	Name
6439	23045	Chain, 36 in. to 45 in. with 56864 and
		56865
Not	e: When	ordering No. 6439, state length required.
4879	23045	Chain Connecting Link
56864	23045	" Hook (large)
56865	23045	" " (small)
42281	23045	Lifting Lever
42282	23045	"
1288R	23045	" " " Screw
<b>1</b> 301D	23045	" Hinge Screw
25033	23045	" " Spring
440F	23045	" " Stop Screw
1547J	23045	" " " Nut
4881 -	23045	Treadle
4882 \	23045	" Shaft
4883	23045	" Spring
4884	23045	" Stand
4885	23045	Treadle complete, Nos.4879, 4881 to 4884
		and two wood screws 1 in. No. 16
42283		Foot Lifter complete, Nos. 440F, 1288R,
		1301D,1547J,4885,6439,25033,42281
		and 42282

### KNEE LIFTER PARTS

No.	Plate			Name
42281	23045	Lifting :	Leve	, 
42282 .	23045	Ħ	17	Bracket
1288R ·	23045	41	11	" Screw
1301D ·	23045	#1	11	Hinge Screw
17886	23045	Ħ	Ħ	Pi tman
25033 /	23045	11	Ħ	Spring
440F	23045	er	et	Stop Screw
1547J	23045	11	Ħ	" " Nut
2763	23045	Rock Sha	ft	
12242 ·	23045	<b>4</b> #	Ha	anger with two wood screws 1
•		in.	No. 1	10
2765	23045	Rock Sha	ft Kr	nee Arm

No.	Plate	Name
2766	23045	Rock Shaft Knee Arm Hub with 356C
356C	23045	-" " " Set Screw
2768 ·		Rock Shaft Knee Arm complete, Nos. 2765
		to 2767
2767	23045	Rock Shaft Knee Plate with 356C
<b>3</b> 560	23045	" " " Set Screw
6337 -	23045	" Lifting Bracket with two 356C
7125 .	23045	* " Hook
356C	23045	" " " " Set Screw
356C	23045	" " " Set Screw
2770	23045	" " Stop Dog with 140219C
140219C	23045	" " " Set Screw
42143	23045	Rock Shaft complete, Nos.2763,2768,6337,
		7125 and two each 2770 and 12242
42284		Knee Lifter complete, Nos. 440F, 1288R,
		1301D,1547J,17886,25033,42143,42281
		and 42282

## KNIFE GRINDER

No.	Plate			N	lame			
41326	23044	Emery	Whee 1	L <b></b>				
1508C	23044	#1	#	Clampin	ng Nut.			
41327	23044	11	#	Shaft				
41328	23044	n	#	" F	Pulley	with	10360	c
1036C.	23044	ŧ1	Ħ	17	li.	Set S	crew	
41513	23044	41	tr.	Washer.				
41329	23044	Frame		1036C				
878D	23044	Ħ	011 F	iole Stor	o Screv	/ <b></b> .		• • • • •
41818	23044	Knife	Holde	er with t				
150210	23044	rt .	**					,41332
		a	nd two	each 31	130,77	LD,15	L9E,4	1333
				334				
41331	23044	Knife	Holde	er Bracke				
157E	23044	Ħ	87	H				w
42065	23044	#	H	n		-		• • • • •
1036C	23044	n	11	0	Ħ		"Set	Screw
717C	23044	41	н	n			ew	
1520E	23044	u	17	Ħ	**	H	Nu	t
41333	23044	11	11	Clamp.				
41334	23044		41	Ħ	Spring	ğ		
14222	23044	17	71	#	Steady	/ Pin		
771D	23044		11	ti	Thumb	Scre	٠	
970D	23044	11	11	Regula	ating ?	(humb	Scre	w
313C	23044	Ħ	"	Screw	Center	٠		
1519E	23044	#	"		#	Nu	t	
41332	23044	*	#	Spring	g			
					-			

No. Plate 41819 23044

Name

Knife Grinder complete, Nos. 717C,1508C,
1520E, 41326 to 41329, 42065,
150210, two each 878D, 41513 and
three wood screws 1 1/4 in. No. 12..

#### THREAD UNWINDER

(FOR ONE SPOOL)

No.	Plate	Name
225259	23046	Spool Rest with 201018C
		-
150203	23046	" " Cushion (felt)
150078	23046	" " Rod
200383C	23046	" " Set Screw
201018C	23046	" " Set Screw
202490	23046	" Stand with 200383C
150079	23046	Thread Guide with 208E
208E	23046	" " Screw
150080	23046	Thread Unwinder complete, Nos. 150078,
		150079, 150203, 202490, 225259 and
		three wood screws 7/8 in. No. 12
27739	23046	Thread Cone (wood) for large cones
Note	: No. 27	7739 is used with, but not included in
	150080.	

Genuine Singer Needles should be used in Singer Machines.
These Needles and their Containers are marked with the Company's Trade Mark "SIMANCO." 1

Needles in Containers marked

"For Singer Machines"

are not Singer made needles.

#### NUMERICAL LIST OF PARTS

No.	Plate	Name
93C	23041	Needle Bar Thread Retainer Screw
133F	23042	Knife (movable) Holder Screw for 132927.
157E	23040	Feed Rock Shaft Crank Clamping Screw for 42021.
157 <b>E</b>	23044	Knife Grinder Knife Holder Bracket Clamping Screw for 41331
171F	23038	Needle Bar Connecting Rod Guide Screw
171F	23041	" Guard Screw
171F	23038	Spreader Lever Connection Guide Screw
175E	23038	Knife (movable) Lever Connection Cap Screw for 42217
190D	23040	Feed Dog Screw
190J	23042	Frame Side Cover (right) Lock Spring Screw for 132604
190J	23042	Frame Top Cover Extension Screw
190D	23040	Presser Lever Lifter Screw (front)
197 <b>J</b>	23041	Spreader Screw
197F	23041	Thread (needle) Take-up Screw
207J	23042	Feed Eccentric Cover Screw for 132604
208E	23046	Thread Unwinder Thread Guide Screw for
		150079
217J	23041	Thread (needle) Eyelet Screw
220E	23042	Knife (movable) Holder Cap Screw for 132927
223F	23041	Needle Bar Connecting Link Hinge Pin Set Screw for 42291
228J	23041	Needle Bar Thread Retainer Bracket Screw
229E	23039	Cloth Plate Extension (bottom) Screw for 132503
229E	23039	Cloth Plate Extension (top) Screw for 132503.
233J	23040	Feed Regulator Stop Screw for 42014
233J	23040	Presser Foot Chaining-off Finger Screw for 132516.
233J	23042	Thread (looper) Eyelet Screw for 42242
236J	23039	Cloth Plate Lock Spring Screw for 132503
283D	23042	Feed Eccentric Cover Holder Thumb Screw.
313C	23044	Knife Grinder Knife Holder Screw Center
		for 150210
330W	23039	Frame Side Cover (left) Screw
330W	23039	" " (right) Screw
336F	23042	Knife (movable) Holder Guide Set Screw
		for 42038
337W	23042	Frame Top Cover Extension Chaining-off Finger Screw for 132931

\_L

No.	Plate	Name
356C	23045	Rock Shaft Knee Arm Hub Set Screw for
3560	23045	2766
356C	23045	" " Lifting Bracket Hook Set Screw
0000	20040	for 6337
356C	23045	Rock Shaft Lifting Bracket Set Screw for 6337
424C	23038	Balance Wheel Set Screw for 42001
440F	23045	Lifting Lever Stop Screw for 42283 and 42284
453C	23038	Feed Eccentric Set Screw for 42011
462C	23038	" Lifting Eccentric Set Screw for
*000	2000	132506
462C	23041	Needle Bar Bushing Set Screw for 42485
462C	23040	Thread (looper) Tube Set Screw
621E	23042	Knife (movable) Holder Guide Plate Screw
62 <b>4</b> C	23041	Needle Bar Crank Shaft Bushing Set Screw for 42485
717C	23044	Knife Grinder Knife Holder Bracket Stop Screw for 41819
742F	23039	Frame Top Cover Screw
742F	23040	Throat Plate Screw
7710	23044	Knife Grinder Knife Holder Clamp Thumb
1112	20011	Screw for 150210
828C	23042	Tension (looper thread) Screw Stud for 42418
878D	23044	Knife Grinder Frame Oil Hole Stop Screw
		for 41819
896C	23038	Needle Bar Connecting Rod Cap (lower) Screw for 42057
896C	23038	Needle Bar Connecting Rod Cap (upper) Screw for 42057
896C	23038	Spreader Lever Connection Cap (lower) Screw for 42075 Spreader Lever Connection Cap (upper)
		Screw for 42075
896C	23038	Spreader Lever Connection Cap (upper) Screw for 42075
904C	23041	Needle Bar Connecting Link Hinge Pin Set Screw for 42104
916C	23042	Tension (needle thread) Screw Stud for 44209
935E	23044	Machine Cushion Screw for 42086
949E	23042	Arm Screw
949E	23042	Knife (movable) Lever Bracket Screw
970D	23044	Knife Grinder Knife Holder Regulating
0100	OII	Thumb Screw for 150210
1012E	23040	Feed Regulator Connection Adjusting Screw for 42015
1036C	23040	Feed Rock Shaft Hinge Pin Bushing Set Screw
1036C	23038	Frame Rotary Shaft Bushing (front) Set
10000	20000	Screw

No.	Plate	Name
10360	23038	Frame Rotary Shaft Crank Set Screw for
		42211
10360	23038	Frame Rotary Shaft Flanged Bushing(back)
		Set Screw
1036C	23042	Knife (movable) Lever Hinge Stud Set
		Screw for 132512
1036C	23044	Knife Grinder Emery Wheel Shaft Pulley
		Set Screw for 41328
1036C	23044	Knife Grinder Knife Holder Bracket Hinge
		Stud Set Screw for 41329
1036C	23041	Looper Lever Hinge Stud Set Screw
1057C	23038	Feed Connecting Rod Cap Screw for 42008.
1057C	23041	Needle Bar Connecting Bracket Clamping
		Screw for 42291
1094D	23038	Spreader Lever Connection 011 Tube and
		Bracket Screw
11010	23041	Knife (stationary) Holder Screw
11200	23040	Presser Lever Hinge Stud Set Screw
1253C	23040	Feed Bar Hinge Pin Set Screw for 42205
1258C	23041	Needle Bar Crank (back) Set Screw for
		42103
12580	23041	Needle Bar Crank (front) Set Screw for
		42104
1259C	23040	Feed Regulator Set Screw for 42014
1259C	23041	Needle Bar Crank (back) Ball Stud Set
		Screw for 42103
1259C	23041	Needle Bar Crank (back) Position Screw
7.05.00	* 05043	for 42103
1259C	23041	Needle Bar Crank (front) Position Screw
10500	97041	for 42104
1,259C	23041	Spreader Lever Ball Stud Set Screw for
1259C	23041	42073 Spreader Lever Hinge Pin Bushing Set
12090	20041	• •
1288R	23045	ScrewLifting Lever Bracket Screw for 42283
TAGON	20040	and 42284
130 <b>1</b> D	23045	Lifting Lever Hinge Screw for 42283 and
10010	20010	42284
1324C	23040	Presser Foot Screw
1354C	23038	Balance Wheel Position Screw for 42001
13730	23038	Feed Connecting Rod Hinge Screw
1373C	23040	" Regulator Connection Hinge Screw
1373C	23038	Knife (movable) Lever Connection Hinge
		Screw
1374C	23040	Feed Regulating Screw Stud
1375C	23038	Frame Rotary Shaft Crank Position Screw
		for 42211
13760	23041	Knife (stationary) Holder Regulating
		Thumb Screw
1378J	27040	Pressure Regulating Thumb Screw
	•	-

180

ra		NUMERICAL LIST OF PARTS
No.	Plate	Name
1407E	23043	Machine Base Thumb Screw for 3 in. table
		(Accessories)
1408E	23043	Machine Base Thumb Screw for 2 in. table
		(Accessories)
1437D	23039	Cloth Plate Hinge Screw
1508C	23044	Knife Grinder Emery Wheel Clamping Nut
1519E	23044	for 41819
10101	NOOTI	Nut for 150210
1520C	23038	Feed Connecting Rod Hinge Screw Nut
1520C	23040	" Regulator Connection Hinge Screw Nut
1520C	23038	Knife (movable) Lever Connection Hinge
1520E	23044	Screw Nut
20,702	20011	Screw Nut for 41819
1520C	23041	Looper Lever Connecting Link Hinge Screw
1534D	23041	Nut.
T004D	23041	Knife (stationary) Clamping Stud Thumb
1547J	23045	Lifting Lever Stop Screw Nut for 42283
		and 42284
1547J	23040	Presser Lever Lifter Screw (back) Nut
1560¢	23042	Tension (looper thread) Regulating Thumb
		Nut for 42418
1560C	23042	Tension (needle thread) Regulating Thumb Nut for 44209
1655E	23039	Cloth Plate Hinge Screw Nut
1680C	23040	Feed Regulating Screw Stud Nut
1737C	23041	Needle Clamping Nut
2102	23042	Tension (looper thread) Disc for two- thread chain stitch
2102	23042	Tension (needle thread) Disc
2763	23045	Rock Shaft for 42143
2765	23045	" Knee Arm for 2768
2766	23045	" " " Hub with 356C, for
		2768
2767	23045	Rock Shaft Knee Plate with 356C, for 2768
2768		Rock Shaft Knee Arm complete, for 42143, Nos. 2765 to 2767
2770	23045	Rock Shaft Stop Dog with 140219C, for
4389	23042	42143
4718	23044	Arm Dowel Pin
4822	23043	Wrench for 1547 (Accessories)
4879	23045	Foot Lifter Chain Connecting Link for
. =		4885
4881	23045	Treadle for 4885
4882	23045	" Shaft for 4885
4883	23045	* Spring for 4885

No.	Plate	Name
4884	23045	Treadle Stand for 4885
4885	23045	Treadle complete for 42283, Nos. 4879,
		4881 to 4884 and two wood screws 1
		in. No. 16
6337	23045	Rock Shaft Lifting Bracket with two 356C,
		for 42143
6439	23045	Foot Lifter Chain, 36 in. to 45 in., with
0101		56864 and 56865, for 42283
7125	23045	Rock Shaft Lifting Bracket Hook for
, 1200		42143
8908	23043	Wrench for 1520 and 1655 (Accessories).
9842	23043	Machine Base Thumb Screw Spring Washer
		(Accessories)
10107	23041	Needle Bar Thread Retainer Spring
10148	23042	Tension (looper thread) Spring for two-
2022		thread chain stitch
10148	23042	Tension (needle thread) Spring
12242	23045	Rock Shaft Hanger with two wood screws 1
		in. No. 10, for 42143
14063	23043	Machine Base Thumb Screw Spring (Ac-
		cessories)
14222	23044	Knife Grinder Knife Holder Clamp Steady
		Pin for 41818
*15404		Trade Mark for 42485
15405		" " Rivet for 42485
17886	23045	Lifting Lever Pitman for 42284
19044	23042	Feed Eccentric Cover Holder Thumb Screw
		Washer
25033	23045	Lifting Lever Spring for 42283 and 42284
27739 *	23046	Thread Unwinder Thread Cone (wood) for
		large cones, for 150080
29599	23038	Spreader Lever Connection Oil Tube Pack-
		ing (felt) for 42106
38534	23041	Needle Bar (hollow)
39541	23040	Presser Foot Screw Washer
40247	23041	Needle Bar Connecting Link Hinge Pin
41326	23044	Knife Grinder Emery Wheel for 41819  " " Shaft for 41819
41327	23044	
41328	23044	p
		1036C, for 41819 Knife Grinder Frame with 1036C, for 41819
41329	23044	Knife Grinder Frame with 10000,101 41010
41331	23044	Kniie Holder Blacket with
		157E, for 150210
41332	23044	Knife Grinder Knife Holder Spring for
		150210
41333	23044	Knife Grinder Knife Holder Clamp for
		150210 Knife Grinder Knife Holder Clamp Spring
41334	23044	Knife Grinder Mille norder Clamb Spring
		for 150210 Knife Grinder Emery Wheel Washer for
41513	23044	41819
		41819

wy ,		TOMERICAL LIST OF PARTS					
No.	Plate	Name	غر		No.	Plate	Name
41818	23044	Knife Grinder Knife Holder with two			42084	23040	Thread (looper) Tube
		14222, for 150210			42086	23044	Machine Base with three wood screws
41819	23044	Knife Grinder complete, Nos. 7170,15080,	ر				1 1/4 in. No. 12 and four each 935E,
		1520E, 41326 to 41329,42065,150210,		`			4718, 42088 and 66707
		two each 878D, 41513 and three wood			42088	23044	Machine Cushion (felt) for 42086
		screws 1 1/4 in. No. 12			42089	23043	Wrench for 1324,1374 and 1737 (Accesso-
42001	23038	Balance Wheel, 2 3/16 in. pulley, with					ries)
		424C and 1354C			42090	23043	Threading Wire (Accessories)
42005	23039	Cloth Plate Lock Spring for 132503			42096	23042	Thread (needle) Eyelet, for two-thread
42007	23040	Feed Bar Hinge Pin					chain stitch
42008	23038	" Connecting Rod with two 1057C			42098	23040	Feed Rock Shaft Hinge Pin
42011	23038	" Eccentric with two 453C			42101	23042	Frame Side Cover (right) Lock Spring for
42013	23038	" Lifting Eccentric Connection					132604
42014	23040	Regulator with 233J and two 1259C			42102	23042	Feed Eccentric Cover Holder for 132604
42015	23040	" Connection with 1012E			42103	23041	Needle Bar Crank (back) with 1258C and
42016	23040	" " Hinge Stud					two 12590
42019	23040	" Rock Shaft for 42020	*	u	42104	23041	Needle Bar Crank (front) with 904C,1258C
42020		Feed Rock Shaft complete, Nos. 42019 and					and 1259C
		42021			42105	23041	Needle Bar Crank Shaft
42021	23040	Feed Rock Shaft Crank with 157E, for			<b>4</b> 2106	23038	Spreader Lever Connection Oil Tube and
		42020			.0.1	00043	Bracket with 29599
42024	23038	Frame Rotary Shaft Bushing (front)			42115	23041	Needle Bar Thread Retainer Bracket
42026	23038	" " Flanged Bushing (back)			42128	23042	Thread (needle) Take-up, for two-thread
		with 54967			401.47	07045	chain stitch
42028	23039	Frame Side Cover (right) hinged			42143	23045	Rock Shaft complete for 42284, Nos.2763, 2768,6337,7125 and two each 2770 and
42038	23042	Knife (movable) Holder Guide with 336F					12242
42039	23042	" " " Plate			42205	23040	Feed Bar with 1253C
42040	23042	DOLOW EXPONDION			42203 42210	23038	Frame Rotary Shaft
	07040	Pin for 132927			42211 -	23038	" " " Crank with 1036C and
42041	23042	Knife (movable) Holder Spring			#W#1	20000	1375C
42042	23042	" " Hinge Stud			42217	23038	Knife (movable) Lever Connection with
42045	23042 23040	Presser Lever Hinge Stud for 132605	•	•	1001	**	two 175E
42045 42049	23040	Knife (stationary) Stud for 42309			42219	23042	Looper, for two-thread chain stitch
42052	23041	Looper Lever Connecting Link			42221	23038	Spreader Lever Ball Stud
42053	23041	" " Hinge Stud			42231	23039	Cloth Plate Extension (bottom) for
42055	23041	Needle Bar Connecting Link					132503
42057	23038	" " Rod with four 8960			42242	23042	Thread (looper) Eyelet, for two-thread
42065	23044	Knife Grinder Knife Holder Bracket Hinge					chain stitch
0003	20044	Stud for 41819			42250	23041	Spreader
42071	23040	Presser Lever Spring			42253	23041	Needle Bar Bushing for 42485
42073	23041	Spreader Lever with 12590			42281	23045	Lifting Lever for 42283 and 42284
42074	23038	Needle Bar Crank (back) Ball Stud			<b>4</b> 2282	23045	" Bracket for 42283 and 42284
42075	23038	Spreader Lever Connection with four 8960			42283		Foot Lifter complete, Nos. 440F, 1288R,
42077	23038	Needle Bar Connecting Rod Guide					1301D,1547J,4885,6439,25033,42281
42077	23038	Spreader Lever Connection Guide	•	-			and 42282
42078	23041	" Hinge Pin			42284		Knee Lifter complete, Nos. 440F, 1288R,
42079	23040	Feed Rock Shaft Hinge Pin Bushing					1301D,1547J,17886,25033,42143,42281
42079	23041	Spreader Lever Hinge Pin Bushing	•	•			and 42282
42082	23042	Tension (needle thread) Thread Guide			42290	23040	Feed Regulating Screw Stud Nut Washer

No.	Plate	Name
42291	23041	
42231	23041	Needle Bar Connecting Bracket with 223F and 1057C
42305	23042	Knife (movable)
42306	23042	" " Gib for 132927
42309	23042	
42310	23041	(Stationary) with 42049
		" Clamping Stud
42367	23038	Frame Rotary Shaft Front Bearing 011 Pad (braided cotton)
42418		Tension (looper thread) Screw Stud 8280
		with 1560C, for two-thread chain
		stitch
42483	23041	Needle Bar Thread Retainer Disc
*42485		Arm with 15404 and two each 4620, 6240,
		15405, 42253 and 42487
42487	23041	Needle Bar Crank Shaft Bushing for 42485
44209		Tension (needle thread) Screw Stud 9160
		with 15600
50117C	23041	Looper Set Screw for 132870
50378 <b>F</b>	23040	Presser Lever Lifter Screw (back)
50562C	23041	Looper Lever Connecting Link Hinge Screw
54967	23038	Frame Rotary Shaft Flanged Bushing(back)
		011 Pad (braided cotton) for 42026
56864	23045	Foot Lifter Chain Hook (large) for 6439.
56865	23045	" " " (small) for 6439.
66707	23044	Machine Cushion Screw Washer for 42086
120341	23043	Tweezers (curved) Accessories
120344	23043	Oiler (copper plated) with 120345 (Ac-
		cessories)
120345	23043	Oiler Spout, 4 1/2 in. long, for 120344.
120440	23043	Screw Driver (Accessories)
132300	23042	Frame Top Cover Extension for 132931
132501	23039	Cloth Plate for 132503
132502	23039	Extension (top) for locator.
132503	23039	Cloth Plate complete, Nos. 42005, 42231, 132501,132502, two 236J and five 229E
132504	23040	Feed Dog, 14 teeth (10 teeth to the
TOTOGE	20040	inch) for 132521
132505	23042	Feed Eccentric Cover for 132604
132506	23038	" Lifting Eccentric with two 462C
*132507		Frame
132508	23039	" Top Cover
132511	23042	" Top Cover Extension Chaining-off
		Finger for 132931
132512	23042	Knife (movable) Lever Bracket with 10360
132513	23041	" (stationary) Holder
132514.	23041	Looper
132515	23041	Needle Guard
132516	23040	Presser Foot with 233J and 132517

No.	Plate	Name
132517	23040	Presser Foot Chaining-off Finger for
		132516
132518	23040	Presser Lever for 132605
132519	23040	" Lifter
132520	23041	Thread (needle) Eyelet
132521	23040	Throat Plate for 132504
132604		Feed Eccentric Cover Holder 42103 with
		42101, 132505, 132931 and two each
		190J and 207J
132605		Presser Lever 132518 with 42045
132638	23039	Frame Side Cover (left) with 132701
132701	23039	" " " Handle for 132638
132870	23041	Looper Lever with 50117C
132883	23041	Thread (needle) Take-up
132926	23042	Knife (movable) Holder for 132927
132927		" " 132926 with 133F,
		42040, 42306, 132928 and two 220E
132928	23042	Knife (movable) Holder Cap for 132927
132931		Frame Top Cover Extension 132300 with
		132511 and two 337W, for 132604
140219C	23045	Rock Shaft Stop Dog Set Screw for 2770
150078	23046	Thread Unwinder Spool Rest Rod for
		150080
<b>1</b> 50079	23046	Thread Unwinder Thread Guide with 208E,
		for 150080
150080	23046	Thread Unwinder complete, for one spool,
		Nos. 150078, 150079, 150203, 202490,
_		225259 and three wood screws 7/8 in.
		No. 12
150203	23046	Thread Unwinder Spool Rest Cushion (felt)
		for 150080
150210	23044	Knife Grinder Knife Holder 41818 with
		970D, 41331, 41332 and two each 313C,
	·	771D,1519E,41333 and 41334,for 41819
200383C	23046	Thread Unwinder Spool Rest Rod Set Screw
	07040	for 202490
2010180	23046	Thread Unwinder Spool Rest Set Screw for
000400	00040	225259,
202490	23046	Thread Unwinder Spool Stand with 200383C,
005050	07046	for 150080
225259	23046	Thread Unwinder Spool Rest with 201018C,
		for 150080

