

MACHINE NO. 107W2

6-5-50

MACHINE NO. 107W2

* 210701 Arm
203087 " Cap
200278H " " Screw
202248 " " " Washer
203089 " " Spool Holder Base
203090 " " " " " 203089 with 200079H and 204296
200585H " " " " " Screw
204296 " " " " Wire
200079H " " " " " Hinge Screw
203088 Arm Cap and Spool Holder complete, Nos. 203087, 203090 and two
200585H
204235 " Position Pin
200010E " Screw
202005 " " Washer
202249 " Shaft with 200357E and 224392
202243 " " Bushing (back) with 202244
202244 " " " " Oil Packing (wick)
200338C " " " " Set Screw
207080 " " " (front) with 202244
202244 " " " " Oil Packing (wick)
200502B " " " " " " Thumb Screw
200341C " " " " Set Screw
210503 " " Connection Belt
202635 " " " " Pulley with 200327C, 200602E and
two 202253
200602E " " " " " Position Screw
200327C " " " " " Set Screw
202253 " " " " " Spring Flange

MACHINE NO. 107W2

224392 Arm Shaft Oil Packing (wick)
200357E " " " " Stop Screw
202255 Balance Wheel (belt groove 2-1/8 in. diam.) with 200328C
and 200335C
200328C " " Position Screw
200335C " " Set Screw
* 210760 Bed
202258 " Hinge Connection (2)
200570E " " " Screw (4)
210761 Bed Plate (back)
210762 " " 210761 with 210763 and two 200132D
200577H " " (back) Screw
210616 " Slide (front)
210530 Bobbin
210846 " Case Base
210729 " " Cap with 200592C, 201016C and 210845
210915 Bobbin Case Cap complete, Nos. 200964C, 210729, 210736 and
210914
210913 " " Latch
210914 " " " 210913 with 210734 and 210735
210735 " " " Fulcrum
210734 " " " Lever
210736 " " " Spring
200964C " " " Stop Screw
210764 " " Stop
200076D " " " Screw
210845 " " Tension Spring
201016C " " " " Regulating Screw

MACHINE NO. 107w2

200592C Bobbin Case Tension Spring Screw
210847 Bobbin Case complete, Nos.210846 and 210915
210681 Face Plate
202135 " " Position Pin
200462B " " Thumb Screw
210512 Feed Bar
210513 " " 210512 with 200641C,201522E and 202623
200641C " " Hinge Screw (driving)
201522E " " " " Nut
202276 " " Slide Block
210514 " " " " Crank with 200035E
210515 " " " " " 210514 with 200253D,201531E and
202276
200035E " " " " " Pinch Screw
200253D " " " " Hinge Screw
201531E " " " " " " Nut
210702 " Dog
200106E " " Screw (2)
202297 " Driving Connection with 200054E and 202277
202624 " " " Crank with 200038C
200038C " " " " Pinch Screw
200545C " " " Hinge Screw
201518E " " " " " Nut
202277 " " " Oil Packing (wick)
200054E " " " Pinch Screw
202300 " " Eccentric Regulating Bracket
203098 " " " " " 202300 with 202635,
two each 201014C and
201525E

MACHINE NO. 107w2

201014C	Feed Driving Eccentric Regulating Bracket Hinge Screw
201525E	" " " " " " " Nut
202301	" " " " " Plunger
202595	" " " " " Spring
200607C	" " " " " " Stop Screw
201014	" " " " " Stop Screw
200429C	" " " " " Screw
200383C	" " " " " Check Screw
202623	" " Rock Shaft
202625	" " " " Stop Collar with two 200383C (2)
200383C	" " " " " Set Screw
202306	" Lifting Connection with 200054E and 202277
* 210645	" " " Crank
210589	" " " " 210645 with 200050C and 200378C
200050C	" " " " Pinch Screw
200378C	" " " " Set Screw
202307	" " " Eccentric with 200382C and 200437C
200437C	" " " " Position Screw
200382C	" " " " Set Screw
200545C	" " " Hinge Screw
201518E	" " " " " Nut
202277	" " " Oil Packing (wick)
200054E	" " " Pinch Screw
210531	" " Rock Shaft (hollow) and Hook Driving Shaft Bearing
202625	" " " " Stop Collar with two 200383C
200383C	" " " " " Set Screw

MACHINE NO. 107w2

202310	Feed Regulating Spindle with 202311,202443 and 202619
* 202311	" " " Head
202443	" " " " Pin
202619	" " " " Position Pin
210738	Guide
210739	" Lever
210740	" " 210739 with 201520H and 210751
210741	" " Hinge Stud
201516E	" " " " Nut
210742	" " Rest Pin
210743	" " Spring
210744	" " " Position Pin
210745	" " Switch Connection
210746	" " " " 210745 with 201520H,201528H and 210748
210747	" " " " Bushing
210748	" " " " Cam
201520H	" " " " " Check Nut
210749	" " " " Fork
201528H	" " " " " Check Nut
210750	" " " " " Hinge Pin
210751	" " Thrust Stud
201520H	" " " " Nut
200098F	" Screw
210763	" Stop Block
200132D	" " " Screw
200459D	" Thumb Screw
210532	Hook (sewing)

MACHINE NO. 107w2

210716	Hook 210532with 200145C,203101, 210541,210703 and three/ 200596F
210776	Hook and Bobbin Case complete,Nos.210716 and 210847
210614	" Driving Bevel Pinion (steel), 24 teeth, with two 200378C
200378C	" " " " Set Screw
210535	" " " " Shaft
202661	" " " " " Belt Pulley with 202324 and two 200378C
200378C	" " " " " " " Set Screw
202324	" " " " " " " Spring Flange
210703	" Gib
200596F	" " Screw
203101	" Oil Wick
200915F	" Position Screw
210537	" Shaft (hollow)
210615	" " Bevel Gear (steel) 24 teeth with two 200382C
200382C	" " " " Set Screw
210539	" " Bushing
210621	" " " 210539 with 200931F and 210537
200335C	" " " Set Screw
200363C	" " " " "
202355	" " " " " Packing (brass)
200931F	" " Position Screw
210541	" Washer Needle Guard
200145C	" " " " Screw
237837	Knee Lifter Connection Lever with 202446
210876	" " " " 237837 with 202447,210875 and two 200262H
200224H	" " " " Hinge Screw

MACHINE NO. 107w2

202447	Knee Lifter Connection Lever Lifting Rod with 202302
202302	" " " " " " Cotter Pin
202446	" " " " Pin
210875	" " Lifting Lever
200262H	" " " " Hinge Screw
202976	Needle Bar (hollow) with 200141F
210543	" " Connecting Link
202333	" " " " Stud with 202254
202254	" " " " Oil Packing (wick)
200383C	" " " " Set Screw
200374C	" " " " " " "
210544	" " " Stud with 202277
210585	" " " " 210544 with 210882
210882	" " " " Oil Packing (wick)
210882	" " " " Swivel with 200387C
210725	" " Crank with 200335C, 200374C, 200383C, 200428C and 202333
203172	" " " Friction Washer
200428C	" " " Position Screw
200335C	" " " Set Screw
210726	" " " complete, Nos. 202398 to 202400, 210543, 210585 and 210725
210546	" " Frame with 200070C
210542	" " " 210546 with 202976
210547	" " " Guide Stud
200334C	" " " " Set Screw
210548	" " " Hinge Stud
200334C	" " " " Set Screw

MACHINE NO. 107W2

210705	Needle Bar Frame Pitman
210706	" " " " 210705 with 202277, 210712, two each 200919C and 201618E
210557	" " " " Eccentric Stud
200070C	" " " " " " Set Screw
202277	" " " " Oil Packing (wick)
200387C	" " Set Screw
200141F	" Set Screw
210779	" Vibrator Cam
210780	" " " 210779 with 200378C and 200383C
200378C	" " " Set Screw
200383C	" " " " "
210718	" " " Shaft
210551	" " " " Bearing and Cover
200566D	" " " " " " " Screw (4)
210559	" " " " Collar with two 200378C
200378C	" " " " " Set Screw
210712	" " Crank with 200378C and 200917C
224353	" " " Link
200919C	" " " " Hinge Screw (lower or upper)
201618E	" " " " " " " " Nut
210723	" " " " Oil Tube
200917C	" " " Position Screw
200378C	" " " Set Screw
210711	" " " Shaft
210560	" " Gear (spiral) with two 200382C
200382C	" " " Set Screw

MACHINE NO. 107w2

203172	Needle Vibrator Gear Thrust Washer
210555	" " Pinion (spiral) with two 200382C
200382C	" " " Set Screw
210708	" " Switch Lever with 200378C and 200917C
210752	" " " " 210708 with 210749 and 210750
202446	" " " " Fork Pin
200917C	" " " " Position Screw
200378C	" " " " Set Screw
210713	" " " Return Lever with 202446
210722	" " " " " Adjusting Plate
200157B	" " " " " " " Screw
200224H	" " " " " Hinge Screw
210714	" " " " " Spring (spiral)
210715	" " " " " " Rod
201528E	" " " " " " Nut
228043	" " " " " Washer
200325C	" " " " " Stop Screw (lower or upper)
201518E	" " " " " " (lower or upper)Nut
202506	Presser Bar (hollow)
202509	" " Auxiliary Bar with 200543H
202510	" " " " Collar with 200141F
200141F	" " " " " Set Screw
200543H	" " " " Foot Screw
202512	" " " " Pin
210753	" " " " Spring
* 206904	" " Bracket

MACHINE NO. 107w2

202507	Presser Bar Bracket 206904 with 200387C
210754	" " " 202507 with 202509, 202510, 202512 and 210753
200387C	" " " Set Screw
225832	" " " Stop Collar with 200113F
200113F	" " " " " Set Screw
207072	" " Bushing (short)
200352C	" " " Set Screw
202554	" " Lifter
200653C	" " " Hinge Screw
210789	" " Lifting Releasing Lever Bracket
200260D	" " " " " " Guide Screw
206608	" " " " " " Spring
202337	" " Position Guide
202338	" " " " Lever with 200086F
200086F	" " " " " Pinch Screw
200352C	" " " " Set Screw
210758	" " Spring
202346	" " " Stop Rod
200492B	" " Thumb Screw (pressure regulating)
200475B	" " " " Thumb Set Screw
202355	" " " " " " " Packing (brass)
202090	" Foot Hinge Pin
210755	" " Plate
210756	" " Shank
210757	Presser Foot (hinged) complete, Nos. 202090, 210755 and 210756
210591	Take-up (auxiliary) for Swivel
200132E	" " Screw

MACHINE NO. 107w2

202398	Take-up Lever
202399	" " Driving Stud with 202277
202277	" " " " Oil Packing (wick)
202400	" " Hinge Stud with 202423
202423	" " " " Oil Packing (wick)
200383C	" " " " Set Screw
202401	" " Oiling Felt
200132E	" " " " Screw
244048	Tension Disc (back)
244049	" " (front)
202404	" Release Plunger
202405	" " Washer
202407	" Spring
200625F	" Stud with 204925
200084F	" " Set Screw
204925	" " Washer
201572B	" Thumb Nut
202409	Tension complete, Nos. 200625F, 201572B, 202405, 202407, 202410, 244048, and 244049
202410	Thread Controller Spring
202411	" " Spring Stop
200132E	" " " " Screw
210593	" Guide (lower)
224387	" "
200172H	" " Screw
210595	" " (on side of arm)
202412	" " (on top of arm)
210592	" " (upper)