Singer 24-35

Form E 361
Revised
January 31, 1917
COPY FOR M. T. D. FILE

ILLUSTRATED

PRICE LIST OF PARTS



MACHINE No. 24-35

THE SINGER MANUFACTURING COMPANY

ILLUSTRATED

PRICE LIST OF PARTS

FOR

MACHINE NO. 24-35

	80.	PAG	E .	٠.		NAME	Ē.		EACH
Serial	765	_	Arm,	uppe	er and	lower	(solid)		s —
	9712	3	"						
	1811	4	66	"ec	"	Roller	and S	Stud	20
	3110	3	"	. 44	"			e (front)	
	310a	4	"	"	"		, cc	(back)	08
	15 1 6a	3	166	"	"	44	44	. 44	
			Nu	t					05
Serial	766							1 28931	1 00
	9504	4	Balar	nce V	Vheel	, 2¼ i	n. pı	illey, with	
			424	c			·		90
	424 c	4	Balar	ice W	heel	Set Scre	w,		05
	9573	4	***		· "	Cover			25
	168в	3	. 46		"	" S	crew.		04
	22306	4						12в	5 0
	1012_{B}	3		ce .	i.	Adjust	ing So	rew	05
	44A	3		"	"	Screw.	Stud.		10
Serial	767	_	Cloth	Plat	e				2 00
	387в	3	44,	".	Sere	w			06
	9935	_	Face	Plate					25
	337в	3	44	"	Screv	w			02
	9732	3	Loop	er wit	h 344	18			60
Serial	28931	4	. "						03
	34418		44	W	sher.	• • • • • • • • •			01
•	9560	_	Need						40
	3 4170	4	44	**	Con	necting	Link	with two	
			1313	Ве					25

ILLUSTRATED

PRICE LIST OF PARTS

FOR

MACHINE NO. 24-35

	NO.	PAGE	NAME	EACH
Serial	765	_	Arm, upper and lower (solid)\$	
	9712	3	" Rock Shaft with 1811	60
	1811	4	" " Roller and Stud	20
	3110	3	" " Screw Centre (front)	08
	310a	4	" " " (back)	08
	1516в	3		
			Nut	05
Serial	766	_		1 00
	9504	4	Balance Wheel, 21/4 in. pulley, with	
			424c	90
	424c	4	Balance Wheel Set Screw	05
	9573	4	" " Cover	25
	168в	3	" " Screw	04
	22306	4	Connecting Rod with two 1012B	50
	1012в	3	" " Adjusting Screw	05
	44A	3	" Screw Stud	10
Serial	767		Cloth Plate	2 00
	387в	3	" Screw	06
	9935	_	Face Plate	25
	337в	3	" " Screw	02
	9732	3	Looper with 34418	60
Serial	28931	4	" Set Screw	03
	34418		" Washer	01
	9560		Needle Bar	40
	34170	4	" Connecting Link with two	
			1313 г	25

. 2	PF	LIT.	IS FOR MACHINE NO. 24-35	
	NO. PA	GE	NAME	EACE
	1313е	4	Needle Bar Connecting Link Adjusting	
·			Screw\$	02
	9570	4	Needle Bar Connecting Stud with $207E$.	30
	207E	4	" " " Clamping	
			Screw	02
	9611	3	Needle Bar Thread Tube	08
	230 _A -	<u> </u>	" Set Screw	02
	9588 -		Presser Bar	40
	9531	4	" Guide with 462c	20
	462c	4	" " Set Serew	02
	7	3	" Lifter with 9533	20
		3	" " Steady Spring	03
*	3 T T T T T T T T T T T T T T T T T T T	4	" Stop Pin	02
		4	" " Screw	06
		4	" " " Nut	03
• •		4 .	" " Spring	06
		3	" Foot:	50
		4	" Screw	02
		3	Tension Body and Screw Stud	40
	.,	3	" Disc	- 05
•	1543в —	_	" Regulating Thumb Nut	05
		3	" Spring	.05
	9715	3	Tension complete, Nos. 414p, 1543B,	
	170		9717 and two 9716	60
		3. 3	Tension Thread Guide Stud	04
	- 1	3	nook (double)	05
			DOIGW	02
	* .	3	Thread Eyelet (flat)	05
			opring Plate	05
		-	Over spoor Fin	20
,	337в 3 9543 3		bcrew	02
			Nipper Disc	02
	9544 3 228p 3		Cover	. 12
	228p 3 9545 3		ocrew	02
Cont. 1			opring,	05
Serial Serial	638		Throat Plate, 3% in. slot	75
Serial	901 244 _A 4	-	Z4	75
Serial	244A 4 761 —		" " Screw Thread Eyelet complete, 22 in. rod	$\begin{array}{c} 03 \\ 25 \end{array}$

