## SINGER 261-1

Form 21195 (561)
Printed in U.S.A.

LIST OF PARTS COMPLETE

FOR


NO. 261-1 MACHINE


## SINGER\* 261-1 PARTS


## THE SINGER COMPANY

Copyright ©1962 by The Singer Company
All Rights Reserved under Inter-American Copyright Union
Copyright under International Copyright Union

Printed in U. S. A.







## LIST OF PARTS 261-1

FIDI	OF PARIS	NAME	COMPONENTE	CODE	PART NUMBER	NAME	COMPONENTS
CODE	PART NUMBER 143615	NAME Oil Shield (felt) upper	COMPONENTS	97	147070	Arm Hole Plug Screw Washer	
1 2 3	143614 143552	Oil Shield (felt) upper Oil Shield (felt) lower BUSHING (back) COMP.	143485	98	23103	Connecting Link and Hinge Pin	
4	143485	Bushing (back)	with 143551	99 100	1047 141163	Set Screw Shaft Screw (left)	
56	143551	Oil Seal (rubber)		101	446 139534	Set Screw Hinge Stud	
7	443 143486	Set Screw Bushing (front)		103	1253 139030	Set Screw (2) Bushing Cover	
9	1520 128551	Stud Nut Lock Washer		105 106	139031	Cover Gasket	
10 11.	139069 1057	CRANK Pinch Screw	with 1057	107	143443 140331	Bushing (left) Set Screw	
12 13	143484 139509	Looper Holder Shaft Gasket (3)		108	143462	LOOPER ECCENTRIC CONNECTION	with 1047
14 15	139510 454	011 Plug (3) Set Sarew		109	143461	LOOPER ECCENTRIC AND FEED LIFTING ECCENTRIC	with two 1036
16 17	198	Screw (2) Washer (2) Thread Cutter		110 111	1036 139432	Set Screw (2) Feed Lifting Eccentric	
18 19	29043 139181 143524	Thread Cutter Thread Guide		112	143451	Forked Connection Slide Block	
20	143524 456 1167	Set Screw Adjusting Screw		113 114	143450 143449	Slide Block FEED ECCENTRIC	
9011234 1156789012234	1167 51781 130130	Nut Guard Holder				(adjustable) COMPLETE	with 217, 7071, 50328 and two 51061
24	139120 143479 143480	Screw Stud (2)		115 116	217 51061	Screw Set Screw (2)	
25 26	143465	Position Pin (2) LOOPER GATE (left) LOOPER GATE (left) LOOPER GATE (left)	143464 with 51282 and 143470	116 117 118	50328 7071	Feed Regulating Screw Clamping Washer	
	143467 143469	LOOPER GATE (left)	143466 with 51282 and 143470 143468 with 51282 and 143470	119 120	376 141001	Bracket Screw Pressure Regulating Thumb	
27 28	143470 51282	Lock Spring Screw		121	51614	Screw	
29	143464	Looper Gate (left) for 21/32" Throat Plate		122	139158	Lock Nut Needle Thread Guide (2)	
	143466	Looper Gate (left) for 3/4" Throat Plate		123	139158 139180	Looper Thread Guide (2) Needle Thread Guide	
	143468	Looper Gate (left) for 3/4" Throat Plate Looper Gate (left) for 7/8" Throat Plate		124	139177	Bracket Thread Eyelet	
30 31	143483 26276			125 126 127	207 146612	Screw Guide Pin	
32	141158 143482	Position Pin (2) Socket 3crew(2) LOOPER HOLDER (front) LOOPER HOLDER (back)	with 181159 06076	127 128	316 1547	Stop Screw Nut	
01234507890 333333333333334	143481	LOOPER HOLDER (back)	with 141158, 26276 with 141158, 26276	129	15444 143512	STOP SCREW Presser Bar Spring	316 with 1547
36	140393 143612	Clamping Screw (2) DRIVING ARM CONNECTION Cap Screw (4) Ball Screw Stud	with four 175	130 131 132	68002 <b>●</b> 143447	Tension Bracket Face Plate	
38	175 139070	Ball Screw Stud		133	143543	Gasket	
40	1047 139496	Set Screw DRIVING ARM	with 1047	134 135 136	146694 1057 146751	LIFTING BRACKET Pinch screw	with 1057
41 42	143613 139097	DRIVING ARM 139496 SHAFT COLLAR	with 1047 with 139070 and 143612 with 1454	137 138	146752	Bushing (lower) PRESSER BAR STOP	with 190
43 44	1454 446	Pinch Screw Set Screw		138	190	Presser Bar Stop Pinch Screw	
43 44 45 46	139074 143463	Slide Block Stud		139 140	190 139462	Presser Foot Screw Presser Bar	
47 48	202 140999	Screw (4) Plug Screw		140 141	1133 139138 <b>5</b>	Set Screw PRESSER FOOT (triple	with 37160, 139134,
49 50 51	143435 140295	Screw Gasket Cover Screw (14)				hinged)	139135, 139137,146167 and three 26276
51 52	143433 143434	Bed Cover Gasket (cork)		142 143	37160 26276	Spring (small) Hinge Pin (3)	
53	51570	Tension Regulating Thumb Nut (2)		144	139134	Presser Foot Plate (back)	
54	59537	Spring Bushing (large) (2)		145 146	139137 146167	Presser Foot Shank Plate Connection	
55 56	131741	Tension Spring (2) Spring Bushing (small)		147	139135	Presser Foot Plate (front)	
	59538	(2)		148 149	139281 1255	Thread Tube (side)	
2/ 58	32572 2102	Tension Disc (4)		150	443 1520	Feed Dog Sorew Set Sorew Lock Nut	
60	50326 54988	Releasing Disc (2) Tension Disc (4) Tension Screw Stud (2) Releasing Pin (2) Thread Turks (2)		151 152	139516	Hinge Pin (eccentric) Slide Block	
55566666666666666666666666666666666666	131696 146676	Lifting Bracket Lifter		153 154 155 156	139046 <b>⊞</b> 704	Screw (short)	
63 64	807 143510	Hinge Screw Lifting Lever		156	172 140440	Screw (long) Plug Screw	
65 66	802 59539	Hinge Screw TENSION SCREW STUD (2)	50326 with 51570	157	12982	Needle Bar Bushing (upper)	
67890 AR 3456789	161 110	Extension Screw (2) Hinge Screw (2)		158 159	1133 143492	Set Screw Oil Wick Guide Tube	
69 70	146620 54872	Connecting Link CRANK	with 624	160	143427	ARM ROTARY SHAFT	143426 with 140359, 143236, 143494
71 72	140610 624	Arm Hole Flug Screw Set Screw		161	143494	CONNECTING LINK	with 139533 and 143495
73 74	143511 140050	Lifting Lever Spring Screw (upper) Screw (2)		162 163	140061 143495	Pinch Screw STUD	with 140061 and 143619
75 76	1443 121449	Screw (2) Clamping Plate		164 165 166	139533 143426	Screw Cap ARM ROTARY SHAFT	with 1036 and 140542
77 78	139366 68003	Slide		167	140542 1036	Position Screw Set Screw	
79	121586	Releasing Shaft Lap Seam Feller (adjustable)		168 169	1036 140552 147079	Hinge Stud Clamping Screw Eyelet Bushing (2) Needle Thread Take-up	
80	229 <b>1</b> 40061	Screw (4) Screw (lower) (3)		170 171	143523 1 <b>297</b> 7	Needle Thread Take-up Needle Bar Bushing (lower	)
80 81 82 83	206	Screw		172 173	1133 143488	Set Screw Needle Bar	•
ده	143498	Needle Guard (3/32 to 3/16" Gauge)		173 174 175	143497 139116 <b>≅</b>	Thread Guide	with two 1498
01:	143541	Needle Guard (7/32 to 9/32" Gauge) Looper Thread Guide		176 177	1498 143489 <b>a</b>	Needle Set Screw (2)	143488 with 139116
84 85 86 87	143487 143452 <b>⊡</b>	Looper Thread Guide Looper (back) Looper (front)		178	691		and 143497
86 87	143453 <b>5</b> 143472	Looper (front) LOOPER GATE (right)	143471 with 51282 and 143477	179 180	139538	Throat Plate	
	143474 143476	LOOPER GATE (right) LOOPER GATE (right) LOOPER GATE (right)	143473 with 51282 and 143477 143475 with 51282 and 143477	181 182	143457 120	Oil Connection Screw (2)	
88 89	143477 51282	Lock Spring Screw		183	143459 143460	Slide Block Cover (back) Slide Block Cover (front)	
90	143471	Looper Gate (right) for		184 185	1324 139257	Pinch Screw CRANK	with 1324
	143473	Looper Sate (right) for		186	143491	OIL WICK	143490 with 146703 and two 146580
	143475	Looper Sate (right) for 3/4" Throat Plate Looper Gate (right) for 7/8" Throat Plate Hinge Pin (2)		187 188	146580 146703	Oil Wick Clip (2) Oil Wick Clamp and	,
91	143478	Hinge Pin (2)	with 51360	189	143490	Retainer Oil Wick	
92	139535	COLLAR AND SUPPORT	with 51369 and two 1253	190 191	1485 143500	Screw (2)	with two each 143124
93 94 95 96	139537 <b>5</b> 143448	Feed Dog Feed Bar		192	226		and 143125
95 96	225 51369	Plug Screw Pinch Screw		193 194	143125 143124	Sleeve Nut (6) Sleeve (6)	
	<b>E</b> Stat	e gauge required		195	143126	Sleeve Adaptor (5)	
	● Ster	e color required					