SINGER 880-3

```
243760
          Face Plate
 200166
                      Screw
 240744
          Feed Eccentric
 1257
                          Stud
 1620
                          Nut
          Frame with 243653, 243652, 243741, 243775, & two 243655
**243764
243646
                End Cover with 350366
243647
                          Gasket
200099
                          Screw
9633
          Looper, (left hand)
243765
                  (right hand)
243746
                  Shaft with 250589AL and 350590AL
            11
243742
                        End Thrust Adjusting Collar with two 2003920
22811111
         Machine Cushions
228448
                  Locating Stud
243604
                  Pulley (aluminum casting)
350419
                         Adjusting Screw (Armshaft)
243654
         Needle Bar with 9611 and 200141F
243656
                     Connecting Link
           15
243657
                                Stud with 200086ALX and 206758
24.3658
                    Driving Connection with 243659 and 243660
243767
                             Crank, complete
243769
                             Shaft, complete
243770
                        Ħ
                                   Oil Control Rod
350643
                                       Metering Screw
201753
                               17
                                                Nut
```

```
243771
         Needle Bar Driving Shaft Oiling Wick
243772
                   Oiling Felt
243798 Oil Level Indicator
243799
                             0-Ring
21,3667
            Reservoir Gasket
200064
                      Screw
243774 Presser Bar with 200110D
243673
                    Lifter
                 11 11
200201
                           Hinge Screw
243776
                    Lifting Bracket with 200110D
243781
                    Spring Guide Rod
1121
                    Thumb Screw
200507
                Foot Thumb Screw
        Puller Feed Clutch, complete
237046
243612
        Pulley Shaft Sleeve, complete
200958
                         Set Screw
200262
        Roller Lifter Hinge Screw
21:3696
        Tension, complete
243782
                Thread Guide
243791
        Thread Guide, complete
24,3602
        Throat Plate Gasket
691X
                     Screw
```

```
約90056H
            Base, Dual Head Machine
 490059H
            Belt Guard (right hand)
 490087H
                       Screw
 490039斑
            Face
                  Plate.
※490066H
            Frame
              17
 490054H
                  End Cover
              Ħ
                         11
 490020H
                             Gasket
 490024H
            Lead Screw
 490055H
                       Crank, complete
             11
                   11
 490022H
                       Nut
 490025H
                       Spacer
 490030H
            Looper Shaft Pulley
 490031H
                                 Ball Bearing
*490081H
           Machine Pulley Shaft
 490082H
                    Support Bracket
490053H
           Main Shaft
 490051H
                       Drive Pulley
490037H
                       Housing for 490038H
             11
                   11
490038н
                                Ball Bearing
             11
490014H
                                Bolt
490050H
                       Sliding Pulley
                   11
490048H
                                       Drive Key
            Ħ
490019H
                       Retaining Collar, complete
490033H
           Needle Bar Driving Connection, complete
490089H
                   Set Screw
```

NOTE: For 10" Machine, use appropriate part number and add the letter "L".

```
490015H
           Oiling Felt Retainer
490068н
           Pillow Block (left)
             11
490069H
                         (right)
490017H
                         Aligning Stud
490070H
                         Ball Bearing
490090H
           Presser Bar for Adjustable Welt Feet
490065H
                       Lifter (left hand)
490018H
                       Spring
490062H
                  Foot (right)
490063H
                        (left)
490091H
                       Adjustable (right)
490092H
                                   (left)
490058H
           Puller Belt Guard, complete
490029H
                  Clutch Connecting Rod for 240744
490040H
                  Gear (lower) complete
             17
490071H
                       (upper) complete
490057H
                  Guard (rear) complete
490036H
                  Roller, Neoprene, complete
490080Н
                  Shaft (upper)
490083Н
                        (lower)
490076Н
                                Pressure Stud Support
490077H
                                Center Support
490078H
                                Clutch (inside)
                           11
490079Н
                                        (outside)
490032H
          Pulley Shaft Connection Belt
490034H
          Roller Lifter Eccentric
```

```
490075H
           Roller Lifter Eccentric Screw
490035H
                         Shaft
490085Н
                                Cam
490086H
                                Nut
490072H
                  Pressure Adjusting Nut
             11
490073H
                                      Stud
490074H
             Ħ
                            Spring
490084H
           Scale
490021H
           Slide Bar
490023H
                     Hold-Down
490049H
          Sliding Fork
490013H
                        Screw (short)
                    11
490075H
                               (long)
490016H
          Stripper Bar
490088н
                        Screw
490012H
          Stud, Attachment
490027H
          Sub-Plate (right)
490028H
                     (left)
490075H
                     Hold-Down Screw
490064H
          Thread Guide (left hand)
490060H
          Throat Plate (right)
490061H
                         (left)
490093H
                        Gasket (left)
          Thumb Nut, Attachment (front)
490011H
1,90010H
                                 (rear)
```