

SINGER
112G127

LIST OF PARTS
FOR
MACHINE NO. 112 G 127

PART NO.	DESCRIPTION
248290	ARM WITH 202135
224002	ARM CAP
200278-819	ARM CAP SCREW
202248	ARM CAP SCREW WASHER
204235	ARM POSITION PIN (2)
200004-805	ARM SCREW (3)
202005	ARM SCREW WASHER (3)
248277	ARM SHAFT WITH 224392 AND 350431
240802	ARM SHAFT BUSHING (BACK) WITH 202244
202244	ARM SHAFT BUSHING (BACK) OIL PACKING (WICK)
200338-803	ARM SHAFT BUSHING (BACK) SET SCREW
207080	ARM SHAFT BUSHING (FRONT) WITH 202244
202244	ARM SHAFT BUSHING (FRONT) OIL PACKING (WICK)
200502-819	ARM SHAFT BUSHING (FRONT) OIL PACKING THUMB SCREW
200341-802	ARM SHAFT BUSHING (FRONT) SET SCREW
224195	ARM SHAFT CONNECTION BELT (REINFORCED NEOPRENE)
224200	ARM SHAFT CONNECTION BELT PULLEY WITH 200327, 200602 AND TWO 202253
200602-805	ARM SHAFT CONNECTION BELT PULLEY POSITION SCREW
200327-803	ARM SHAFT CONNECTION BELT PULLEY SET SCREW
202253	ARM SHAFT CONNECTION BELT PULLEY SPRING FLANGE (2)
224138	ARM SHAFT CONNECTION BELT TIMING COLLAR WITH 200113
200113-806	ARM SHAFT CONNECTION BELT TIMING COLLAR SET SCREW
224139	ARM SHAFT CONNECTION BELT TIMING PLATE
200164-819	ARM SHAFT CONNECTION BELT TIMING PLATE SCREW (2)
224392	ARM SHAFT OIL PACKING (WICK)
350431-805	ARM SHAFT OIL PACKING STOP SCREW
224144	ATTACHMENT SLIDE PLATE WITH 213479 AND 236061
236061	ATTACHMENT SLIDE PLATE FRICTION SLIDE
213479	ATTACHMENT SLIDE PLATE FRICTION SLIDE SPRING
224105	BED WITH 203376
054897	BED OIL CUP
223852	BED SLIDE (BACK)
223811	BED SLIDE (BACK) STOP
223812	BED SLIDE (BACK) STOP SPRING
223853	BED SLIDE (FRONT) FOR USE WITH THROAT PLATES IN GAUGES FROM 3/16 TO 5/8 INCH
224043	BED SLIDE (FRONT) FOR USE WITH THROAT PLATES IN GAUGES FROM 23/32 TO 3/4 INCH
203470	BOBBIN (2)
248459	BOBBIN CASE (CHROMIUM PLATED)
203648	BOBBIN CASE LATCH
202056	BOBBIN CASE LATCH PIN
203473	BOBBIN CASE LATCH PLUNGER
203474	BOBBIN CASE LATCH SPRING

LIST OF PARTS
FOR
MACHINE NO. 112 G 127

PART NO.	DESCRIPTION
241674	BOBBIN CASE OILING FELT
241675	BOBBIN CASE OILING FELT RETAINER
350405-803	BOBBIN CASE OILING FELT RETAINER SCREW (2)
224004	BOBBIN CASE OPENER
224005	BOBBIN CASE OPENER LEVER WITH 201349, 201542 AND 203101
201349-803	BOBBIN CASE OPENER LEVER DRIVING SCREW STUD
201542-803	BOBBIN CASE OPENER LEVER DRIVING SCREW STUD NUT
203101	BOBBIN CASE OPENER LEVER DRIVING SCREW STUD OIL PACKING (WICK)
265088	BOBBIN CASE OPENER LEVER HINGE STUD WITH 202277
202277	BOBBIN CASE OPENER LEVER HINGE STUD OIL PACKING (WICK)
200364-803	BOBBIN CASE OPENER LEVER HINGE STUD SET SCREW
223623	BOBBIN CASE OPENER LEVER LINK
200118-804	BOBBIN CASE OPENER SCREW
236083	BOBBIN CASE TENSION SPRING
201016-806	BOBBIN CASE TENSION SPRING REGULATING SCREW
200594-803	BOBBIN CASE TENSION SPRING SCREW
203216	BOBBIN CASE WASHER (CLOTH)
248460	BOBBIN CASE CPL. (2) NOS. 200594, 201016, 202056, 203216, 203473, 203474, 203648, 236083, 241674, 241675, 248459 AND TWO 350405
237804	FACE PLATE
202135	FACE PLATE POSITION PIN
200473-819	FACE PLATE THUMB SCREW
224050	FEED BAR WITH 200336 AND 201535
224051	FEED BAR WITH 224050, 200040, 225837 AND 267273
350393-803	FEED BAR HINGE SCREW (DRIVING)
201518-805	FEED BAR HINGE SCREW NUT
211786	FEED DOG, FOR 248286
221446	FEED DOG, FOR 248292
211792	FEED DOG, FOR 248294
200106-805	FEED DOG SCREW (2)
200336-805	FEED DOG SUPPORT SCREW
201535-805	FEED DOG SUPPORT SCREW NUT
224106	FEED DRIVING CONNECTION WITH 200049 AND 202277
201407-803	FEED DRIVING CONNECTION HINGE SCREW
201517-805	FEED DRIVING CONNECTION HINGE SCREW NUT
206758	FEED DRIVING CONNECTION HINGE SCREW OIL PACKING (WICK)
202277	FEED DRIVING CONNECTION OIL-PACKING (WICK)
200049-804	FEED DRIVING CONNECTION PINCH SCREW
202300	FEED DRIVING ECCENTRIC REGULATING BRACKET
224140	FEED DRIVING ECCENTRIC REGULATING WITH 202300 224200, TWO EACH 201408 AND 201525

LIST OF PARTS
FOR
MACHINE NO. 112 G 127

PART NO.	DESCRIPTION
201408-803	FEED DRIVING ECCENTRIC REGULATING BRACKET HINGE SCREW (2)
201525-805	FEED DRIVING ECCENTRIC REGULATING BRACKET HINGE SCREW NUT (2)
202301	FEED DRIVING ECCENTRIC REGULATING BRACKET PLUNGER
202595	FEED DRIVING ECCENTRIC REGULATING BRACKET PLUNGER SPRING
200607-803	FEED DRIVING ECCENTRIC REGULATING BRACKET PLUNGER SPRING STOP SCREW
201408-803	FEED DRIVING ECCENTRIC REGULATING BRACKET STOP SCREW
201525-805	FEED DRIVING ECCENTRIC REGULATING BRACKET STOP SCREW NUT
200429-806	FEED DRIVING ECCENTRIC REGULATING SCREW
200383-803	FEED DRIVING ECCENTRIC REGULATING SCREW CHECK SCREW
223650	FEED DRIVING ROCK SHAFT
223651	FEED DRIVING ROCK SHAFT WITH 223650, 201518, 224051 AND 350393
240590	FEED DRIVING ROCK SHAFT CRANK WITH 200019
200019-805	FEED DRIVING ROCK SHAFT CRANK PINCH SCREW
202625	FEED DRIVING ROCK SHAFT STOP COLLAR WITH TWO 200383 (2)
200383-803	FEED DRIVING ROCK SHAFT STOP COLLAR SET SCREW (2)
224154	FEED LIFTING CAM WITH 201220
267273	FEED LIFTING CAM FORK WITH 200173 AND 223655
200040-830	FEED LIFTING CAM FORK SCREW
225837	FEED LIFTING CAM FORK SCREW WASHER
223635	FEED LIFTING CAM OILING FELT
200173-804	FEED LIFTING CAM OILING FELT SCREW
201220-803	FEED LIFTING CAM SET SCREW
224142	FEED REGULATING SPINDLE CPL.
-224016	HOOK (SEWING) (2)
224115	HOOK (2) WITH 224016, 224100, TWO EACH 200590 AND 201253
237204	HOOK AND BOBBIN CASE CPL. NOS. 224115 AND 248460
224019	HOOK BUSHING (LOWER) (BRONZE)
200364-803	HOOK BUSHING (LOWER) SET SCREW
224020	HOOK BUSHING (UPPER) (BRONZE)
200446-803	HOOK BUSHING (UPPER) POSITION SCREW
223867	HOOK DRIVING GEAR (SPIRAL) WITH 200362 AND 201222
201222-803	HOOK DRIVING GEAR POSITION SCREW
200362-803	HOOK DRIVING GEAR SET SCREW
224021	HOOK DRIVING PINION (SPIRAL) WITH TWO 200382
200382-803	HOOK DRIVING PINION SET SCREW (2)
224022	HOOK DRIVING PINION THRUST WASHER
237206	HOOK DRIVING SHAFT
224111	HOOK DRIVING SHAFT BUSHING WITH 202244

LIST OF PARTS
FOR
MACHINE NO. 112 G 127

PART NO.	DESCRIPTION
202244	HOOK DRIVING SHAFT BUSHING OIL PACKING (WICK)
200327-803	HOOK DRIVING SHAFT BUSHING SET SCREW
224112	HOOK DRIVING SHAFT CONNECTION BELT PULLEY WITH 202253 AND TWO 201254
201254-803	HOOK DRIVING SHAFT CONNECTION BELT PULLEY SET SCREW (2)
202253	HOOK DRIVING SHAFT CONNECTION BELT PULLEY SPRING FLANGE
224100	HOOK GIB
201253-806	HOOK GIB SCREW
223849	HOOK SADDLE (LEFT) WITH 200009
224023	HOOK SADDLE WITH 223849, 200364, 200446, 224019 AND 224020
223850	HOOK SADDLE (RIGHT) WITH 200009
224024	HOOK SADDLE WITH 223850, 200364, 200446, 224019 AND 224020
223680	HOOK SADDLE BEARING (LEFT)
200327-803	HOOK SADDLE BEARING (LEFT) SET SCREW
223681	HOOK SADDLE BEARING (RIGHT)
200335-803	HOOK SADDLE BEARING (RIGHT) SET SCREW
200009-805	HOOK SADDLE PINCH SCREW
200006-805	HOOK SADDLE SCREW (2)
225585	HOOK SADDLE SCREW WASHER (2)
237193	HOOK SADDLE (LEFT) CPL. NOS. 200118, 200364, 223623, 224004, 224005, 224021 TO 224023, 237204 AND 265088
240033	HOOK SADDLE (RIGHT) CPL. NOS. 200118, 200364, 223623, 224004, 224005, 224021, 224022, 224024, 237204 AND 265088
224025	HOOK WASHER
200590	HOOK WASHER SCREW (2)
240067	KNEE LIFTER CONNECTION LEVER
200262-819	KNEE LIFTER CONNECTION LEVER HINGE SCREW
223684	KNEE LIFTER CONNECTION LEVER LIFTING ROD WITH 202302
202302	KNEE LIFTER CONNECTION LEVER LIFTING ROD COTTER PIN
206628	KNEE LIFTER CONNECTION LEVER LIFTING ROD SPRING
227227	KNEE LIFTER CONNECTION LEVER LIFTING ROD SPRING COLLAR WITH 200113
200113-806	KNEE LIFTER CONNECTION LEVER LIFTING ROD SPRING COLLAR SET SCREW
248293	KNEE LIFTER LIFTING LEVER
200262-819	KNEE LIFTER LIFTING LEVER HINGE SCREW
248304	KNIFE
240434	KNIFE BAR
248295	KNIFE BAR ANGLE EXTENSION
200126-804	KNIFE BAR ANGLE EXTENSION SCREW (2)
248278	KNIFE BAR DRIVING ECCENTRIC WITH 200382 AND 200437
248305	KNIFE BAR DRIVING ECCENTRIC FORK WITH 200029
200029-805	KNIFE BAR DRIVING ECCENTRIC FORK PINCH SCREW

LIST OF PARTS
FOR
MACHINE NO. 112 G 127

PART NO.	DESCRIPTION
200437-803	KNIFE BAR DRIVING ECCENTRIC POSITION SCREW
200382-803	KNIFE BAR DRIVING ECCENTRIC SET SCREW
202891	KNIFE BAR DRIVING SHAFT CRANK WITH 200694 AND 201525
200694-806	KNIFE BAR DRIVING SHAFT CRANK SCREW STUD
201525-805	KNIFE BAR DRIVING SHAFT CRANK SCREW STUD NUT
237808	KNIFE BAR GUIDE BLOCK
200011-804	KNIFE BAR GUIDE BLOCK SCREW (2)
200330-803	KNIFE BAR GUIDE SCREW
201531-805	KNIFE BAR GUIDE SCREW NUT
202343	KNIFE BAR LIFTING SPRING
234044	KNIFE BAR LIFTING SPRING PLUNGER
237809	KNIFE BAR POSITION BRACKET
201387-806	KNIFE BAR POSITION BRACKET SCREW (2)
248280	KNIFE HOLDER
200190-804	KNIFE HOLDER SCREW (2)
237811	KNIFE HOLDER SWITCH-IN HANDLE
200076-804	KNIFE SCREW (2)
248296	KNIFE SWITCH-IN LEVER
248297	KNIFE SWITCH-IN LEVER CONNECTION STUD
240067	KNIFE SWITCH-IN LEVER CONNECTION LEVER
248302	KNIFE SWITCH-IN LEVER SPRING
244039	KNIFE SWITCH-OUT HANDLE
248298	KNIFE SWITCH-OUT LEVER
350325-803	KNIFE SWITCH-OUT LEVER HINGE SCREW
248299	KNIFE SWITCH-OUT LEVER SPRING
241688	MACHINE PULLEY WITH 141566 AND 141567
141566-803	MACHINE PULLEY POSITION SCREW
141567-803	MACHINE PULLEY SET SCREW
3305-16-2	NEEDLE (2)
248281	NEEDLE BAR AND HOLDER, IN GAUGES FROM 3/16 TO 5/8 INCH, IN STEPS OF 1/32 INCH, WITH TWO 200141
248282	NEEDLE BAR AND HOLDER, IN GAUGES FROM 23/32 TO 3/4 INCH, WITH TWO 200141
238251	NEEDLE BAR CONNECTING LINK
264718	NEEDLE BAR CONNECTING LINK OIL GUARD
201183-804	NEEDLE BAR CONNECTING LINK OIL GUARD SCREW
202333	NEEDLE BAR CONNECTING LINK STUD WITH 202299
202299	NEEDLE BAR CONNECTING LINK STUD OIL PACKING (WICK)
200347-819	NEEDLE BAR CONNECTING LINK STUD SET SCREW
200383-803	NEEDLE BAR CONNECTING LINK STUD SET SCREW
206891	NEEDLE BAR CONNECTING STUD WITH 200086
202329	NEEDLE BAR CONNECTING STUD WITH 206891 AND 202330
202330	NEEDLE BAR CONNECTING STUD OIL PACKING (WICK)
200086-803	NEEDLE BAR CONNECTING STUD PINCH SCREW
202692	NEEDLE BAR CRANK WITH 200335, 200374, 200383, 200432 AND 202333

LIST OF PARTS
FOR
MACHINE NO. 112 G 127

PART NO.	DESCRIPTION
248283	NEEDLE BAR CRANK WITH 202292, 202329, 202399, 202400, 223881 AND 238251
203172	NEEDLE BAR CRANK FRICTION WASHER
200432-803	NEEDLE BAR CRANK POSITION SCREW
200335-803	NEEDLE BAR CRANK SET SCREW
248284	NEEDLE BAR FRAME
237815	NEEDLE BAR FRAME POSITION BRACKET WITH 200330 AND 201531
350129-805	NEEDLE BAR FRAME POSITION BRACKET SCREW (2)
207069	NEEDLE BAR FRAME POSITION PIN
200118-804	NEEDLE BAR FRAME SCREW
210910	NEEDLE BAR FRAME STUD WITH 202277
202277	NEEDLE BAR FRAME STUD OIL PACKING (WICK)
200347-819	NEEDLE BAR FRAME STUD SET SCREW
200141-806	NEEDLE SET SCREW
244033	PRESSER BAR (HOLLOW)
207072	PRESSER BAR BUSHING (2)
200352-803	PRESSER BAR BUSHING SET SCREW (2)
202671	PRESSER BAR LIFTER
200653-803	PRESSER BAR LIFTER HINGE SCREW
207963	PRESSER BAR LIFTING RELEASING LEVER BRACKET
200975-806	PRESSER BAR LIFTING RELEASING LEVER BRACKET GUIDE SCREW
206608	PRESSER BAR LIFTING RELEASING LEVER BRACKET SPRING
207820	PRESSER BAR POSITION GUIDE
202338	PRESSER BAR POSITION GUIDE LEVER WITH 200086
200086-806	PRESSER BAR POSITION GUIDE LEVER PINCH SCREW
200352-803	PRESSER BAR POSITION GUIDE SET SCREW
240172	PRESSER BAR SPRING (FLAT)
210949	PRESSER BAR SPRING BRACKET WITH 200086
200086-833	PRESSER BAR SPRING BRACKET PINCH SCREW
200538-803	PRESSER BAR SPRING REGULATING SCREW
200948-806	PRESSER BAR SPRING SUPPORT SCREW
229288	PRESSER FOOT, 46 NEEDLE HOLE, IN GAUGES FROM 3/16 TO 3/8 INCH, IN STEPS OF 1/32 INCH
229269	PRESSER FOOT, 46 NEEDLE HOLE, IN GAUGES FROM 3/8 TO 3/4 INCH, IN STEPS OF 1/32 INCH
200074-806	PRESSER FOOT SCREW
223881	TAKE-UP LEVER
202399	TAKE-UP LEVER DRIVING STUD WITH 244071
244071	TAKE-UP LEVER DRIVING STUD OIL PACKING (WICK)
202400	TAKE-UP LEVER HINGE STUD WITH 202423
202423	TAKE-UP LEVER HINGE STUD OIL PACKING (WICK)
200363-830	TAKE-UP LEVER HINGE STUD SET SCREW
202401	TAKE-UP LEVER OILING FELT
200132-805	TAKE-UP LEVER OILING FELT SCREW

LIST OF PARTS
FOR
MACHINE NO. 112 G 127

PART NO.	DESCRIPTION
223702	TENSION BRACKET WITH TWO EACH 201224 AND 236060
200159-806	TENSION BRACKET SCREW
248217	TENSION BRACKET CPL. NOS. 200978, 201199, 223702, 223703, 223706, 267368, TWO EACH 200309, 204271, 223438, 223704, THREE 201572 AND FOUR 244048
244048	TENSION DISC (4)
236060	TENSION DISC POSITION PIN (2)
223703	TENSION RELEASE LEVER
236005	TENSION RELEASE LEVER ROD
200309-805	TENSION RELEASE LEVER SCREW (2)
223704	TENSION RELEASE PLUNGER (2)
204271	TENSION RELEASE WASHER (2)
223438	TENSION SPRING (2)
201224-850	TENSION STUD (2)
201572-819	TENSION THUMB NUT (2)
223706	THREAD CONTROLLER DISC
200978-819	THREAD CONTROLLER DISC SCREW
267368	THREAD CONTROLLER SPRING
241360	THREAD CONTROLLER SPRING STOP
200132-805	THREAD CONTROLLER SPRING STOP SCREW
201199-806	THREAD CONTROLLER STUD WITH 204925
200061-803	THREAD CONTROLLER STUD SET SCREW
204925	THREAD CONTROLLER STUD WASHER
201572-819	THREAD CONTROLLER THUMB NUT
224028	THREAD GUIDE
267246	THREAD GUIDE (UPPER)
210954	THREAD GUIDE (LOWER)
200582-819	THREAD GUIDE SCREW (2)
240034	THREAD RETAINER (2)
210956	THREAD RETAINER BRACKET WITH 200397
200582-819	THREAD RETAINER BRACKET SCREW (2)
200366-819	THREAD RETAINER SET SCREW (2)
210993	THREAD RETAINER SLEEVE
223844	THREAD RETAINER SPRING
248287	THREAD RETAINER STUD
210958	THREAD RETAINER STUD COLLAR
248288	THREAD RETAINER STUD COLLAR (WIDE)
200397-819	THREAD RETAINER STUD SET SCREW
248289	THREAD RETAINER (LOWER) (FOR TWO THREADS) CPL. NOS. 210956, 210993, 223844, 248287 AND 248288
248286	THROAT PLATE, 46 NEEDLE HOLE, FOR NEEDLE SIZES 16 AND 18, IN GAUGES FROM 3/16 TO 3/8 INCH, IN STEPS OF 1/32 INCH, FOR 211786
248292	THROAT PLATE, 46 NEEDLE HOLE, FOR NEEDLE SIZES 16 AND 18, IN GAUGES FROM 3/8 TO 5/8 INCH, IN STEPS OF 1/32 INCH, FOR 221446

LIST OF PARTS
FOR
MACHINE NO. 112 G 127

PART NO.	DESCRIPTION
248294	THROAT PLATE, 46 NEEDLE HOLE, FOR NEEDLE SIZES 16 AND 18, IN GAUGES 23/32 AND 3/4 INCH, FOR 211792
200161-804	THROAT PLATE CLAMP SCREW
203376	THROAT PLATE POSITION PIN
000691-806	THROAT PLATE SCREW

ACCESSORIES FOR MACHINE 112 G 127

PART NO.	DESCRIPTION
202258	BED HINGE CONNECTION (2)
200570-805	BED HINGE CONNECTION SCREW (4)
203470	BOBBIN (4)
224121	DRIP PAN, 20 INCH LONG, WITH FOUR 3/4 INCH WIRE NAILS
041400	MACHINE REST PIN (WOOD)
3305-16-2	NEEDLES (10)
120342	OILER (COPPER PLATED) WITH 120343
120343	OILER SPOUT (3-1/2 INCH LONG)
228476	SCREW DRIVER (BOBBIN CASE)
225498	SCREW DRIVER (7-1/4 INCH LONG)
248304	KNIVES (3)
225554	WRENCH

BOBBIN WINDER

259428	BRAKE (LEATHER)
259429	BRAKE CLAMP
200113-806	BRAKE CLAMP SCREW
225453	FRAME WITH 244071 AND 259660
225454	FRAME HINGE PIN
244071	FRAME OIL PACKING (WICK)
259660	FRAME OIL WELL WASHER
225455	FRAME SPRING
225456	FRAME SPRING PLUNGER
259930	PULLEY WITH 457
000457-830	PULLEY SET SCREW
225381	SPINDLE
225444	STOP LATCH
200056-805	STOP LATCH SCREW
225458	STOP LATCH THUMB LEVER
225459	STOP LATCH THUMB LEVER HINGE STUD
225459	STOP LATCH THUMB LEVER JOINT STUD
202478	STOP LATCH TRIP LEVER
200299-819	STOP LATCH TRIP LEVER HINGE SCREW
225461	TENSION BRACKET WITH 201499
200082-804	TENSION BRACKET SCREW
228026	TENSION BRACKET SCREW WASHER
002102	TENSION DISC (2)
013710	TENSION SPRING
201499-819	TENSION STUD
201572-819	TENSION THUMB NUT
225462	BOBBIN WINDER TENSION BRACKET CPL. NOS. 13710, 201572, 225461 AND TWO 2102
259662	BOBBIN WINDER AND TENSION BRACKET BASE
259462	UNIVERSAL BOBBIN WINDER CPL. NOS. 200056, 200082, 200113, 200299, 202478, 225381, 225444, 225453 TO 225456, 225458, 225462, 228026, 259428, 259429, 259662, 259930, TWO EACH 225459 AND WOOD SCREWS 3/4 INCH, NO. 12 R.H.B.

ACCESSORIES FOR MACHINE 112 G 127

PART NO.	DESCRIPTION
	KNEE LIFTER
228713	ROCK LEVER WITH TWO 350231
228707	ROCK LEVER BRACKET WITH 200347 AND THREE WOOD SCREWS 7/8 INCH, NO. 12
228709	ROCK LEVER BRACKET WITH 228707, 228363, 228367, 228386, 228455 AND 228713
228370	ROCK LEVER EXTENSION WITH 200530
350231-803	ROCK LEVER EXTENSION SET SCREW
228363	ROCK LEVER HINGE PIN
228364	ROCK LEVER KNEE PLATE WITH 350231
228388	ROCK LEVER KNEE PLATE ARM
350231-803	ROCK LEVER KNEE PLATE ARM SET SCREW
350231-803	ROCK LEVER KNEE PLATE SET SCREW
228455	ROCK LEVER POSITION SPRING
228365	ROCK LEVER ROD
200530-803	ROCK LEVER ROD SET SCREW
228386	ROCK LEVER SPRING
228367	ROCK LEVER STOP STUD
200347-830	ROCK LEVER STOP STUD SET SCREW
228710	KNEE LIFTER ROCK LEVER CPL., NOS. 228364, 228365, 228370, 228388 AND 228709

(OTHER KNEE LIFTER PARTS ARE LISTED WITH PARTS OF
MACHINE HEAD)

THREAD UNWINDER
(FOR THREE SPOOLS)

228777	THREAD UNWINDER (FOR THREE SPOOLS) CPL. NOS. 228765, 228766, 228767, 228768, 228771, 228774, THREE EACH 150203, 228764, 228769 AND WOOD SCREWS NO. 12, 7/8 INCH LONG
228764	THREAD UNWINDER SPOOL PIN (3)
228765	THREAD UNWINDER SPOOL REST (FOR ONE SPOOL) (FLAT) WITH 201254
228766	THREAD UNWINDER SPOOL REST (FOR TWO SPOOLS) (FLAT) WITH 201254
150203	THREAD UNWINDER SPOOL REST CUSHION (3)
228767	THREAD UNWINDER SPOOL REST ROD
201254-803	THREAD UNWINDER SPOOL REST SET SCREW (2)
228768	THREAD UNWINDER THREAD GUIDE
228771	THREAD UNWINDER THREAD GUIDE HOLDER (FOR THREE GUIDES)
228774	THREAD UNWINDER THREAD GUIDE ROD
-----	THREAD UNWINDER WOOD SCREWS NO. 12, 7/8 INCH (3)

ACCESSORIES FOR MACHINE 112 G 127

PART NO.	DESCRIPTION
	TREADLE COMPLETE
248300	TREADLE
232365	TREADLE CHAIN (41-1/2 INCH LONG) (2) WITH TWO EACH
	202784
202784	TREADLE CHAIN HOOK (2)
017881	TREADLE SHAFT
014369	TREADLE STAND
248301	TREADLE CPL., NOS. 14369, 17881, 248300 AND TWO WOOD
	SCREWS 1-1/2 INCH, NO. 12
-----	TREADLE WOOD SCREWS 1-1/2 INCH, NO. 12

FITTINGS
FEED DOGS

211786	FEED DOG, FOR 248285 AND 248286
221446	FEED DOG, FOR 248292
211792	FEED DOG, FOR 248294

THROAT PLATES

248286	THROAT PLATE, 46 NEEDLE HOLE, FOR NEEDLE SIZES 16 AND 18, IN GAUGES FROM 3/16 TO 3/8 INCH, IN STEPS OF 1/32 INCH, FOR 211786
248292	THROAT PLATE, 46 NEEDLE HOLE, FOR NEEDLE SIZES 16 AND 18, IN GAUGES FROM 3/8 TO 5/8 INCH, IN STEPS OF 1/32 INCH, FOR 221446
248294	THROAT PLATE, 46 NEEDLE HOLE, FOR NEEDLE SIZES 16 AND 18, IN GAUGES 23/32 AND 3/4 INCH, FOR 211792